



Installing the Wondercap Kit

TIMBER FLOOR

Installing the puddle flange Step 1.

Cut a 135mm diameter hole in timber above the drainage pipe.

Step 2.

Route a 3mm deep x 35mm wide recess around the cut hole.

Note: Ensure the flange (1) sits flush with the floor.

Waterproofing Step 3.

Clean, prime and solvent weld the flange (1) tail into the drainage pipe and secure the flange (1) with 4 counter-sunk screws.

Step 4.

Clean and prepare the surface ready for waterproofing and remove the base (2) and foam ring from the flange (1) and set aside.

Step 5.

Apply the waterproofing membrane as per manufacturer's instructions and requirements.

Step 6.

Apply the waterproofing membrane as required to wet areas. Finish the waterproofing membrane over the lip of the flange (1) and into the recess.

WARNING: DO NOT APPLY WATERPROOFING MEMBRANE DOWN DRAINAGE PIPE

Step 7.

Reinsert the base (2) into position once the waterproofing has been completed.

Bedding & Tiling Step 8.

Raise the base to the desired tile height and secure into position with bedding mix.

Step 9.

Screed and tile using the Wondercap base (2) as a reference point / gradient. Simply screed up to base (2).

Step 11.

Apply grout and remove the cap (3) from the base (2).

PRO TIP! – if you have not allowed for the tile thickness, continue tiling to the floor waste. The tiles will finish 10mm above the top of the base & cap. Remove the cap and simply cut the internal edge of the cap to the height required and insert the spacer ring into the base to support the tile grate and finish flush with the tiles.

Step 13.

Install the grate and secure with grout.